

INTERNACIONAL

FRANYUTI S.A DE C.V.

AV. ALCANFORES 107 JARDINES DE SAN MATEO NAUCALPAN EDO. MEXICO 53240 TEL 5373-4360 Y FAX 5373-2145 http://www.franyuti.com

FRANYUTI INC.

2000 S. MAIN STREET SUITE 114 MCALLEN TEXAS. 78503 U.S.A. (956)682-6244 Y FAX (956) 618-3113

1200-HMC CO-POLYMER WHITE PURGE AGENT/CLEANER

USE PROTECTIVE CLOTHING AND GEAR BEFORE BEGINNING







HOW TO FLUSH YOUR SYSTEM:

INSTRUCTIONS FOR USE:

1-WE RECOMMEND MOVING THE HOT MELT SYSTEM TO A SAFE AND VENTILATED AREA FOR FLUSHING.

2-PUMP OR DRAIN AS MUCH ADHESIVE FROM THE SYSTEM AS POSSIBLE INTO A LIQUID TIGHT, HEAT RESISTANT CONTAINER.

3-FILL YOUR TANK WITH 1200-HMC AND REPLACE THE LID. ALLOW TO MELT COMPLETELY. RUN AT THE SAME TEMPERATURE AS YOUR ADHESIVE.

4-REMOVE THE NOZZLES FROM THE GUNS AND FLUSH ENOUGH 1200-HMC THROUGH THE HOSE(S) AND GUN(S) TO DISPLACE ANY REMAINING ADHESIVE.

5-ALLOW THE 1200-HMC TO WORK FOR AT LEAST 20 MIN

6-DRAIN ALL 1200-HMC FROM THE MELT TANK THROUGH THE DRAIN PLUG LOCATED ON THE PUMP BODY. RE-INSTALL THE DRAIN PLUG WHEN THE TANK IS EMPTY.

7-RE-FILL THE TANK WITH YOUR ADHESIVE AND REPLACE THE LID. FLUSH THE REMAINING 1200-HMC THROUGH THE HOSES AND GUNS UNTIL COMPLETELY GONE AND DISCARD FOLLOWING ALL FEDERAL, STATE, LOCAL REGULATIONS FOR DISPOSAL OF SOLID WASTE MATERIAL.

SPECIAL NOTE:

CLEANING THE TANK:

TO PEEL THE RESIDUAL ADHESIVE FROM INSIDE THE TANK, EMPTY THE TANK AND WHILE COOLING USE A SOFT SCRAPING TOOL, CAREFULLY BEGIN THE PEELING PROCESS.